



**Step 4. Rinse** **Ambient Temp** **10 min.**

---

**Repeat Step 1 until pH of water in system and CIP tanks is equal to pH of incoming feed water.**

**NOTE: ALWAYS ADD CAUSTIC BEFORE CHLORINE. NEVER ADD CHLORINE TO A NEUTRAL OR ACID SOLUTION.**

**New cartridges should be kept in their original shipping containers and crates until ready for installation. Cartridges should be stored as follows:**

**Store cartridges indoors and out of direct sunlight.  
Store cartridges at temperatures between 50-85°F/10-30°C.  
Store cartridges at relative humidity below 70%.  
Store cartridges in a horizontal position.**

*For technical assistance, please contact a Cleaning Specialist at (978) 694-7050.  
To place an order, please call our Customer Service Department at (978) 694-7005.*

*The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale for additional information.*

---

**Koch Membrane Systems, Inc., [www.kochmembrane.com](http://www.kochmembrane.com)**

Corporate Headquarters: 850 Main Street, Wilmington, Massachusetts 01887-3388 USA. Tel.: 1-888-677-KOCH.

For related trademark information, visit [www.kochmembrane.com/legal](http://www.kochmembrane.com/legal)  
Koch Membrane Systems, Inc. is a Koch Chemical Technology Group, LLC company.  
© 2019 Koch Membrane Systems, Inc. All rights reserved worldwide.

KPN 1004334-R7